ISO 13 · RFID Counting Dome

ISO 13 confines RFID reading to the carton placed under the dome, preventing tagged items around it from being picked up.

Use

1. Place the carton flat, preferably on the floor, on a stable surface.
2. Cover the carton completely with ISO 13, positioning the elasticated reading sleeve in the centre of the top side of the carton.
3. Position the elasticated hem around the base of the carton.
4. Insert your hand and the RFID reader into the sleeve until the elastic completely surrounds your wrist.
5. Read the carton.

Warning

If tagged items are present on the level below, move the carton to an area where no tags are at risk of being read through the floor before carrying out the count.

After use

After use, gently fold the counting dome and store it.