# ISO Paint 26 · RF shielding paint

## Standards and recommendations

Substrates, preparatory work and application conditions must comply with applicable local standards and good painting practice.

## Substrate preparation

- Substrates must be clean, free of dust and grease.
- Thoroughly wash and sand the surfaces.
- On raw and porous substrates, a first coat of primer / acrylic primer must be applied. Failure to do so may reduce shielding performance.

## Application

- Apply ISO Paint 26 in a single coat, completely covering the substrate.
- Do not apply in freezing conditions, on frozen substrates or substrates in the process of thawing.
- Minimum application temperature: +6 °C.
- Recommended tools: 12 mm anti-drip roller, 13 mm woven polyester roller, polyester brush, spray gun.
- Cleaning and thinning: water.

## Important

If the paint is applied to a floor, it must be covered with a floor covering (carpet, vinyl, parquet, etc.), never with floor paint or varnish.

## Health and safety

Refer to the safety information available on request and to the instructions on the packaging.